

Concentrate

QUICKSTART GUIDE



How to Clean and Disinfect with Prevail Concentrate

Step 1: Dilute Prevail[™] Concentrate to the desired concentration



Can either be diluted with AHP approved equipment or into a container.

AHP1750 Test Strips should be used regularly to confirm proper dilution.

SELECT YOUR DILUTION	ADD PREVAIL™ CONCENTRATE	ADD WATER
PRE-SOAK 1:128	32 mL	4 L
DISINFECTION 1:40 5 min contact time	100 mL	4 L

Solution

Step 2: Dry Clean (Remove Solid Waste)

Using a shovel or scraping tool, remove as much debris and organic material as possible, including feathers, manure, litter, feed.



dust, dirt and cobwebs. Start at the top of the building and work down to the floors, from one end of the building to the other.

Step 3: Pre-soak (if required)

Pre-soak all surfaces and equipment with Prevail Concentrate, using a dilution so of 32 mL concentrate per 4 L water (1:128). Apply from the bottom to top.



PREVail

Step 4: Rinse with Water

Rinse with high pressure water (>1000 psi) working from top to bottom. Use hot water if available.

Step 5: Disinfect

Apply Prevail Concentrate to all surfaces and equipment, using a dilution of 100 mL concentrate per 4 L water (1:40). A foaming applicator is recommended. Using water and pressure from





power washer lines, attach a foaming gun calibrated to deliver a 1:40 dilution. Move the foaming gun quickly and evenly, covering all surfaces and equipment with foam. Work from the bottom upward.

Step 6: Wait 5 Minutes

Wait for the required contact time of 5 minutes to be reached. No need to rinse or wait for surfaces to dry.



For more information visit PrevailFarm.ca





Prevail[™] is a member of the Virox family of brands.

DISCLAIMER: You must read and follow the instructions on the label for our product and use the product for the particular applications specified on the product label. To the full extent permitted under applicable law, Virox Technologies Inc. shall not be liable for any damages whatsoever, arising out of or otherwise in connection with any failure to follow those instructions or any use of its products which is not specified on the product's label. The instructions on the product label are not a warranty, express or implied, and Virox Technologies, Inc. expressly disclaims any implied warranties, including any warranty of fitness for a particular purpose. Under applicable law, some of the above waivers or disclaimers of warranty, or exclusions of liability for certain types of damages may not apply to you. In such cases, our liability will be limited to the fullest extent permitted by applicable law. AHP® and Accelerated Hydrogen Peroxide® and Design are trademarks of Diversey, Inc.